

SEED STARTER (SS2 & SS4) ASSEMBLY INSTRUCTIONS

- 1.** UNPACK ALL CARTONS AND BAG KITS. *COMPARE PARTS TO PARTS LIST ON OPPOSITE PAGE. YOU MAY WANT TO SAVE CARTONS FOR STORAGE OF UNIT WHEN NOT IN USE.*
- 2.** LAY TWO OF THE BENT STEEL RODS (**R**) FLAT (ONE ON TOP OF THE OTHER). SLIDE TWO **LONG** CHAINS (**CL**) OVER THE ENDS AND AROUND BEND. (SEE DIAGRAM)
- 3.** SLIDE A PLASTIC CLAMP (**PC**) OVER EACH END. (SEE DIAGRAM) POSITION THE CLAMPS JUST AROUND BEND. USE A SCREW (**S**) AND NUT (**N**) TO TIGHTEN CLAMPS. THIS WILL NOW BE THE TOP HALF OF THE UNIT.
- 4.** USING ONE REMAINING BENT STEEL ROD (**R**) AND A **SHORT** CHAIN (**CS**). SLIDE THE LAST LINK OF THE CHAIN OVER THE END OF THE ROD AND AROUND BEND. NOW SLIP A STEEL TUBE (**T**) OVER THE END OF THE ROD. REPEAT THIS STEP ON OTHER END.
- 5.** TAKE THE LAST BENT STEEL ROD (**R**) AND SLIDE THE OPPOSITE ENDS OF THE CHAINS OVER AND AROUND BENDS, NOW SLIP THE REMAINING TUBES (**T**) ON. THIS WILL NOW BE THE BOTTOM HALF OF THE UNIT.
- 6.** JOIN THE TOP AND BOTTOM BY SLIPPING THE ENDS OF THE TOP HALF INTO THE TUBES (**T**) OF THE BOTTOM HALF.
- 7.** STAND UP THE "A" FRAME AND SPREAD THE BOTTOM APART.
- 8.** INSTALL THE LAMPS INTO THE FIXTURE. BE SURE LAMPS ARE SEATED PROPERLY BY ROTATING THE NOTCH ON END OF LAMP. ONE NOTCH WILL BE VISIBLE, CENTERED DIRECTLY IN THE SOCKET OPENING.
- 9.** ATTACH FIXTURE ONTO LONG CHAINS (**CL**) USING S-HOOKS (**SH**) ON TOP OF THE FIXTURE (SEE DIAGRAM)

CODE	STAND PARTS	QTY
CS	10" Chains (Frame)	2
T	23" Steel Tubes	4
R	Bent Steel Rods	4
	2 Lamp Shop lite	1
	Grow Lamps	2
BAG KIT (Inside Fixture)		
CL	21" Chains (Fixture)	2
S	Small Screws	2
N	Small Hex Nuts	2
PC	Plastic Ring Clamps	2
SH	S-Hooks	2



SS2

